


# iiNet BizPhone Cordless W76P Quick Startup Guide

## IP DECT W76P Quick Startup Guide



### Packaging Contents

The following contents are included in your W76P package:




**Note:** W76P DECT IP hone consists of one W70B base station and one W56H handset.


### Assembling the Phone

1. Connect the base station power and the network in one of the following ways, as shown below.

a. AC Power Option




b. PoE (Power over Ethernet) Option




2. Attach and remove the base stand.

Attach the Base Stand




Align the snap-fits with the corresponding holes and push forward, snapping them into the holes.

Remove the Base Stand




Remove the snap-fits from the holes horizontally.


3. Insert the battery into the handset.



4. Attach the belt clip to the handset.



5. Connect the charging cradle and charge the handset.



**Note:**

The handset should be used with original power adapter (5V/0.6A) only. The use of the third-party power adapter may cause damage to the base station.

The charging status of the handset is indicated in the top right-hand corner of the LCD screen.

**NOTE:** Not all features mentioned in the Yealink User Guide are available on BizPhone Services

## **START UP THE PHONE**


### **Startup the Phone**

The IP Phone is pre-registered to the base station. After the IP Phone is connected to the network and the power, it will automatically start the initialization process by connecting to TPG BizPhone's servers to obtain the configuration and updates (maximum 10 minutes).

The LCD screen will indicate the current status of the process (initializing or configuration updating). The phone may reboot few time during this process. After the final reboot, the phone is ready to use.

## **BASIC OPERATIONS**

### **Turning Handsets On**

- Press , then the LCD screen lights up.
- Place the handset in the charger cradle. The handset will be turned on automatically.

### **Turning Handsets Off**





- Long press  to turn the handset off.

## **HANDSET SETTINGS**

### **Add a Contact**




- Press the **OK** key to enter the main menu and then select **Directory** and Press **OK**.
- Press the **Options** soft key, and then select **New Contact** and press **OK**.
- Enter the desired values in the **Name**, **Number** and **Mobile** fields.
- Press the **Save** soft key to accept the change.

### **Volume Adjustment**




- Press  or  during a call to adjust the receiver volume aof the speakerphone/earpiece.
- Press  or  when the handset is idle to adjust the ringer volume.

## **BASIC CALL FEATURES**

### **Placing Calls**

- Enter the desired number when the handset is idle.
- Press ,  or  to dial out.

### **Answering Calls**

- Press the **Accept** soft key or press  or press  or press .

### **Ending Calls**

- Press .




### **Call Hold**

- Press **Options** soft key during a call, and then select **Hold** and press **OK**.
- To resume the call, press the **Resume** soft key.




### **Call Transfer – Blind Transfer**

- Press the **Options** soft key during a call, and then select **Transfer** and press **OK**.
- Enter the number you want to transfer the call to.
- Press the **Transfer** soft key.







### **Call Transfer – Attended Transfer**

- Press the **Options** soft key during a call, and then select **Transfer** and press **OK**.
- Enter the number you want to transfer the call to.
- Press ,  or  to dial out.
- Once the receiving party answers, announce the call.
- Press the **Transfer** soft key to complete the transfer.



### **Conference Call**

- Press the **Options** soft key during a call, and then select **Conference**.
- Enter the number you want to transfer the call to.
- Press ,  or  to dial out.
- When the second party answers, press the **Conference** soft key to connect the calls.

### **Call Forward**

- Press **OK** key to enter the main menu, and then select **Call Features -> Call Forward**.
- Press  or  to highlight the desired line, and then press the **OK** soft key.
- Press  or  to highlight the desired forwarding type (Always/Busy/No Answer), and then press the **OK** soft key.
- Select **Enabled** from the **Status** field.
- Enter the number you want to forward the incoming calls to in the **Target** field.
- For **No Answer Forward**, press  or  to select the desired ring time to wait before forwarding in the **After Ring Time** field.
- Press the **Save** soft key to accept the change.

### **Accessing Call History**

- Press **History** soft key.
- Press  or  to choose **All Calls**, **Missed Calls**, **Placed Calls**, or **Received Calls**.

**NOTE:** For more information about other features, refer to the BizPhone User Reference Guide (contact your Administrator)